

Status bar

When the terminal is powered –on, the terminal’s Operating System provides data to display the Status bar as follows. Direct your customer to the status bar to help them understand the device.



Information	Indicator	Description
System Date and Time		This shows the current system time and date.
Power Condition		This indicates that the terminal is connected to mains power.
Battery Level		This is the charge level on the portable device and indicates whether or not the battery is currently charging.
Bluetooth Icon		This is the status of the Bluetooth link between the portable device and the base. Note: The manufacturer’s recommended maximum operating distance for Bluetooth connectivity is 70m.
		This indicates there is a weak Bluetooth signal between the terminal and the base.
		This indicates the terminal has lost Bluetooth connection with the base.
3G/ 4G Indicator		This indicates whether the connection is 3G or 4G.

Essential Lite Only

Ethernet Indicator		This indicates the terminal has connected to Ethernet but there is no internet connection.
		This indicates the terminal has connected to Ethernet and there is internet connection.